

# MULTI-PORT SANITARY VALVES

## 3-WAY SANITARY VALVES



**THE ULTIMATE IN  
AUTOMATION TECHNOLOGY!!!**



**EA-407-SN**

### FEATURES / SPECIFICATIONS:

- Tru-Flo Multi-Port Tri-Clamp Sanitary Ball Valves are supplied in Standard and Encapsulated (Cavity Filled) designs.
- Multi-Port Valves provide a positive seal at every port.
- Direct Mounting ISO5211 Pad facilitates easy automation and installation in space restrictive applications.
- Spring loaded washers create a live loaded, self-adjusting stem assembly reducing in-line maintenance costs
- Ideally suited for high cycle applications in either manual or automated conditions
- Multi-Port Valves reduce costs and simplify flow control enabling shutoff and directional control with a single valve
- 316 Stainless Steel
- Full-Port design in 8-12 Ra finish
- When equipped with Encapsulated (Cavity Filled) Seats, Tru-Flo Multi-Port Sanitary Ball Valves meet or exceed USDA and FDA standards in federally inspected facilities
- Options: Tri-Clamp or Butt-Weld
  - Standard and Encapsulated (Cavity Filled) Styles
  - L-Port or T-Port configuration
  - Sizes 1"-4"

Item	Part name	Material	Qty
1	body	CF8M	1
2	end caps	CF8M	3
3	seat	PTFE	4
4	ball	SUS 316	1
5	stem	SUS 316	1
6	joint gasket	PTFE	4
7	gasket	PTFE	1
8	seal	PTFE	1
9	gland ring	SUS 304	2
10	o ring	VITON	1
11	belleville spring washer	SUS 301	2
12	lever nut	SUS 304	2
13	locking tab	SUS 304	1
14	handle	SUS 304	1
15	plastic coating	PVC	1
16	stop screw	SUS 304	1
17	bolts	SUS 304	16
18	static device	SUS 316	2
19	spring	SUS 316	2

**EA-407-SN**